

# Metal Bath Installation Instructions:

Easy to Install - Hardware Included.

1. Use 7/64" drill bit to start drill hole, 1/8" bit if plastic or metal anchors are used.

NOTE: If plaster or drywall, use of plastic or metal anchor is suggested.

2. Mount item with screws provided.